

Angle Valve Wheel 10 mm

1033302

Wheel for opening and closing the angle valve, which is used to replace the existing wheels on the valves in case of their rupture or damage. Easy mounting on the valves with a screw that is placed in the middle of the wheel.

- Diameter: fi 10 mm

