

Backpack Fire Pump V25

422001H

An initial fire extinguisher with 25 liters of water.

APPLICATION: The hand pump should be removed from the back bracket or disconnected from the bracket and connected to the backpack together with the connecting tube.

Activate the backpack by stretching and tightening the hand pump. Moving the nozzle from the middle to the extreme position results in a full or spray jet.

APPLICATION: The initial fire extinguisher is intended primarily for localizing and extinguishing small forest fires with full or dispersed jet of water, and also for extinguishing initial fires of solids (class A).

CAUTION!

Not for extinguishing electrical appliances.

Tehničke specifikacije

Type of extinguishing agent	water / foam
Edition	Regular Edition
Extinguishing media quantity	25 lit.

