

Uređaj za disanje Ocenco M-20.2 EEBD

2005009

Ocenco M-20.2 sa komprimiranim kisikom EEBD (uređaj za hitnu samoizbavu) kontrolira se na zahtjev, a normalno trajanje tijekom bijega je najmanje 15 minuta, a u mirovanju može pružiti zaštitu do 32 minute.

Pokreće se u nekoliko sekundi, a kisik počinje teći automatski. Jednostavno otkopčajte kućište, izvucite jedinicu i umetnite usnik i kopču za nos. Priložena prozirna kapuljača može se navući u bilo kojem trenutku tijekom bijega. Kombinacija komprimiranog kisika i usnika omogućava nanošenje u prostoru već ispunjenim dimom.

15. godišnji životni vijek omogućuje vrlo nizak trošak održavanja. Godišnji vizualni pregled jedina je potrebna radnja jer boca nije podložna periodičnim pregledima.

Jedinica se isporučuje sa sekundarnim vanjskim spremnikom za pohranu (narančasto). Primarni spremnik je prozirno zatvorena kutija s integriranim nastavkom za nošenje jedinice na remenu.

- Brza i jednostavna upotreba - izvlačenjem jedinice iz kućišta automatski se pokreće protok kisika.
- Niski troškovi održavanja sa 15 godina radnog vijeka koji zahtijevaju samo vizualni pregled.
- Remen za nošenje - tako lagan i kompaktan da se može udobno nositi na pojasu u skućenim prostorima.
- Potpuna vidljivost - prozirna kapuljača štiti korisnika od opasnih okruženja uz istovremeno omogućavanje potpunog vidnog polja.
- Maksimalna zaštita - Teflonska kapuljača i vrećica za disanje pružaju izvrsnu toplinsku i kemijsku otpornost.

Dostupne su dvije varijante: jedna za pomorstvo i druga za rudarstvo i industriju. Varijanta za rudarstvo i industriju nema kapuljaču.

Tehničke specifikacije

Odobrenje: 89/686/EEC Osobna zaštitna oprema	Odobrenje (2): 2014/90/EU Oprema za pomorce
Standard: EN 13794 (na kopnu)	Standard (2) : ISO 23269-1 (pomorstvo)
Materijal: Četka - LiOH	Životni vijek : 15 godina
Dimenzije : 210 x 230 x 100 mm (sekundarni spremnik)	Težina : 1.4 kg / 3.1 lbs



acenco M-20.2 EEBD
EMERGENCY ESCAPE BREATHING DEVICE *

IF THIS GAUGE IS OUT OF THE GREEN ZONE, REMOVE FROM SERVICE

OPERATING INSTRUCTIONS

- 1 REMOVE EEBD FROM ORANGE CASE
- 2 LIFT YELLOW LEVER AND DISCARD COVER
- 3 REMOVE UNIT BY PULLING YELLOW NECK STRAP UPWARDS
- 4 INSERT YELLOW MOUTHPIECE
- 5 FIT YELLOW NOSE CLIP
- 6 INHALE THROUGH MOUTH AND ESCAPE



ADJUST YELLOW NECK STRAP AND DON'T FACE SHIELD IF NEEDED

Small text at the bottom of the instructions, including "acenco, INCORPORATED" and "M-20.2 EEBD".